

# **STEEDA**

## **2000-2002 FOCUS**

### **Rear Wing**

#### **Installation Instructions**

1. Remove the original rear wing. If your car did not come with a wing from the factory that's okay, you will not reuse the factory holes.
2. Take the supplied hole makers and insert them into the mounting holes on the underside of the Steeda wing. Then lay the wing on the back of the car where you want it mounted and center it. Now use some tape and tape down the plastic legs of the hole makers. Do this to both sides of the four of them.
3. Pull off the wing. The hole makers should be taped to your roof so you know where to drill the pilot holes. Drill the four pilot holes. Then finish the four holes with a 1/4" drill bit. Bolt the Steeda wing to your Focus.
4. Paint the wing to the color of your choice. Before bolting it to the car apply a small amount of silicone gasket maker around the hole to prevent leaks.